







F.01U.066.754 Hus for
trekksender Gehäuse für Zugsender
Hus for trekksnorsender


1 **bruker S37**

Insert the S37 into the housing
and clip it





1 **using S87**


Insert the S87 support
and clip it into the housing



Insert the S87 and clip
into the support




2



! Cut for S37 / S87
Für den S37 / S87
abschneiden
Couper pour le
S37 / S87


3



4



5



! Do not tighten the screws too much!
Die Schrauben nicht zu fest anziehen!
Ne pas serrer les vis trop fort !